

# -MODEL 60-19

# **Booster Pump Control Valve**

# with High Capacity Pilot System



# **Schematic Diagram**

ltem	Descri	ntion
ILCIII	Descii	Puon

- 100-03 Powercheck Main Valve 1
- 2 CS3M Solenoid Control
- 3 102C-3H 3-Way Valve
- 4 CVS-1 Shuttle Valve
- X105LCW Switch Assembly 5
- CV Flow Control

## **Optional Features**

Item	Description
Α	X46A Flow Clean Strainer
В	CK2 Isolation Valve

X141 Pressure Gauge

X43 "Y" Strainer

PC PC-22D Pump Control Panel


#### **Designed for Larger Sized Pump Stations**

- **Low Head Loss**
- **Built-in Check Valve**
- **Opening and Closing Rates Separately Adjusted**
- **Proven Reliable Design**

The Cla-Val Model 60-19 Pump Control Valve is a pilot-operated valve designed for installation on the discharge of booster pumps to eliminate pipeline surges caused by the starting and stopping of the pump.

The pump starts against a closed valve. When the pump is started, the solenoid control is energized and the valve begins to open slowly. gradually increasing line pressure to full pumping head. When the pump is signaled to shut-off, the solenoid control is de-energized and the valve begins to close slowly, gradually reducing flow while the pump continues to run. When the valve is closed, a limit switch assembly, which serves as an electrical interlock between the valve and the pump, releases the pump starter and the pump stops.

Should a power failure occur, a built-in lift-type check valve closes the moment flow stops, preventing reverse flow regardless of solenoid or diaphragm assembly position.




## **Typical Installation**

Install Model 60-19 valve as shown. Flexible conduit should be used for electrical connections to the solenoid control and the limit switch. A Model 52-02/652-03 Surge Anticipator Valve is recommended for power failure protection.

Note: For optimum operation of built-in check feature, installation must be with valve stem vertically up.

The Model 60-19 is for 250mm and larger valves or when the pressure is above 300 psi.




# Pressure Ratings (Recommended Maximum Pressure - psi)

Valve Body &	Pressure Class				
valve body 8	Covei	Flanged			Threaded
Grade	Material	ANSI Standards*	150 Class	300 Class	End‡ Details
ASTM A536	Ductile Iron	B16.42	250	640	400
ASTM A216-WCB	Cast Steel	B16.5	285	720	400
UNS 87850	Bronze	B16.24	225	500	400

Note:  $\,\,^{\star}\,$  ANSI standards are for flange dimensions only.

Flanged valves are available faced but not drilled. ‡ End Details machined to ANSI B2.1 specifications.


Valves for higher pressure are available; consult factory for details



# **Materials**

Component	Standard Material Combinations		
Body & Cover	Ductile Iron	Cast Steel	Bronze
100-03 Available Sizes	250 - 400mm	250 - 400mm	250 - 400mm
Disc Retainer & Diaphragm Washer	Cast Iron	Cast Steel	Bronze
Trim: Disc Guide, Seat & Cover Bearing	Bronze is Standard Stainless Steel is Optional		
Disc	Buna-N® Rubber		
Diaphragm	Nylon Reinforced Buna-N® Rubber		
Stem, Nut & Spring	Stainless Steel		


For material options not listed, consult factory. Cla-Val manufactures valves in more than 55 different alloys.





# **60-19 Series Dimensions (mm)**

Valve Size (mm)	250	300	350	400
A Threaded	_	_	_	_
AA 150 ANSI	756	864	991	1051
AAA 300 ANSI	790	902	1029	1105
B Diameter	600	711	832	902
C Maximum	594	744	816	889
<b>D</b> Threaded	_	_	_	_
DD 150 ANSI	378	432	495	526
DDD 300 ANSI	395	451	514	552
E	235	273	321	394
F 150 ANSI	203	241	267	298
FF 300 ANSI	222	260	292	324
G Threaded	_	_	_	_
GG 150 ANSI	219	349	378	399
GGG 300 ANSI	236	368	397	419
H NPT Body Tapping	1.00	1.00	1.00	1.00
J NPT Cover Center Plug	1.00	1.25	1.50	2.00
K NPT Cover Tapping	1.00	1.00	1.00	1.00
Stem Travel	71	86	102	114
Approx. Ship Weight (kgs)	426	760	1116	1406
Approx. X Pilot System	762	940	1041	1092
Approx. Y Pilot System	508	559	610	660
Approx. Z Pilot System	508	559	610	660

# **Sequence Of Operation**







#### Pump Off...

With pump off, static line pressure is transmitted through strainer F, shuttle valve C, solenoid control A, three way valve B, and speed control E to the chamber above the diaphragm, thus holding the valve shut.

If power failure occurs when valve is open, the built-in check valve J closes immediately to prevent reverse flow.

#### Starting Cycle...

Starting switch closes, pump starts, solenoid control A energizes and shifts allowing fluid from three-way valves G and B to drain to atmosphere. High pressure fluid from pump enters strainer B and shifts shuttle valve C, which always supplies the highest pressure from either strainer B or F. High pressure fluid is transmitted to the lower diaphragm chamber through three-way valve G and opens the valve. The opening speed of the valve is controlled by speed control E, which limits the rate fluid is relieved from above the diaphragm to drain.


#### Stopping Cycle...

Starting switch opens, solenoid control A deenergizes and shifts, pump continues to run. High pressure fluid from the pump is directed above the diaphragm through three-way valve B to close the valve.

The valve closes slowly as fluid from the lower diaphragm chamber is gradually released to atmosphere through speed control D and threeway valve G.

When the valve closes fully, the limit switch H shuts off the pump.

# Model 60-19 Flow Chart Uses 100-03 Powercheck Main Valve



Liquid Volume Displaced from Diaphragm Chamber When Valve Opens or Closes					
Sizes (Inches) 250 300 350 400					
60-19 (gallons)	2.51	4.00	6.50	9.57	
660-19 (gallons)	1.26	2.51	4.00	6.50	

### **Valve Sizing**

Sizing Model 60-19 Booster Pump Control Valves is similar to sizing non-modulating type valves. Simply select the smallest size valve that will handle the pump output at an acceptable head loss for the application.

**Do not oversize.** Oversizing a Booster Pump Control Valve will nullify its ability to prevent surges caused by the starting and/or stopping of the pump. Maximum flow values are given in the selection table above. For further information on flow characteristics of this valve, see the 100-03 engineering data sheet.

#### **Drain Provisions**

Each time the valve opens or closes, water is discharged from the solenoid exhaust port, the amount varying with the valve size. Provisions should be made for the disposal of this water. Exhaust tube must be free of any back pressure. Provide an air gap between the solenoid exhaust tube and drain facility.

Cla-Val offers the most complete line of automatic control valves for virtually any type of pump control system available.

Please call your Cla-Val regional office or sales agent for complete design assistance. Our goal is to provide the best automatic control valve solution for each application.

60-19	100-03 Pattern: Globe (G), Angle (A), End Connections: Threaded (T), Flanged (F) Indicate Available Sizes					
Valve Selection	mm	250	300	350	400	
Main Valve 100-03	Pattern	G, A	G, A	G, A	G, A	
	End Detail	F	F	F	F	
Suggested Flow (Liters/Sec)	Maximum	309	442	530	694	
	Maximum Intermittent	387	549	664	863	

#### **Pilot System Specifications**

#### **Temperature Range**

Water to 180°F Max

#### **Materials**

Standard Pilot System Materials
Pilot Control: Low Lead Bronze

Trim: Stainless Steel Type 303
Rubber: Buna-N® Synthetic

Rubber

Optional Pilot System Materials
Pilot Systems are available with
optional Aluminum, Stainless Steel

or Monel materials.

# **Solenoid Control Specifications**

Body:

Brass ASTM B283

Enclosure:

NEMA Type 1,2,3,3S,4,4X general purpose watertight NEMA Type 6,6P,7,9

watertight explosion proof

available.

Voltages:

110, 220 - 50 Hz AC

24, 120, 240, 480 - 60 Hz AC

6, 12, 24, 120, 240 - DC

Others available.

Max. operating pressure differential:

200 psi

Coil:


Insulation molded Class F
Watts AC 6
AC Volt Amps Inrush 30
AC Volt Amps Holding 16
Watts DC 10.6

#### **Wiring Diagram**

Auto-Off-Hand	=	Selector Switch
1CR	=	Relay, DPST Normally Open
2CR	=	Relay, DPST Normally Open
3CR	=	Relay, TPST Normally Open
SW <sub>1</sub>	=	Switch, Remote Start, Automatic
SW <sub>2</sub>	=	Switch, SPDT, Valve Limit Switch
		Connect to N.C. Terminal
PVS	=	Pilot Valve Solenoid
М	=	Pump Motor Starter

 $\underline{\text{Note:}}$  SW2 and PVS supplied by Cla-Val. All other electrical items supplied by customer. SW2 is included in the X105L switch assembly which is mounted on the pump control valve cover.

Shown In Pump Off Position



For simplified field wiring, see Model PC-1 Pump Control Panel Data Sheet.

# When Ordering, Please Specify:

- 1. Catalog No. 60-19
- 2. Valve Size
- 3. Pattern -Globe or Angle
- 4. Pressure Class
- 5. Trim Material

- 6. Electrical Selection
- 7. Desired Options
- 8. When Vertically Installed (Flow Direction)